



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TR824 Renault Kangoo 1998>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	D	2	M16x50 Bolts, Nuts & Washers
B	2	Angle Brackets	E	2	M10x90 Bolts, Nuts & Washers
C	2	19 x 51 Spacer Bushes	F	2	M10x70 Bolts, & Washers
			G	2	M10 x 35 Bolts & Washers
			H	4	10 x 40 Flat Washers
			J	2	10 x 50 Flat Washers
			K	2	10 x 25 Flat Washers

1. Temporarily remove the rear exhaust rubbers, exhaust mounting bracket and heat shield.
2. Locate Item **B** into the existing slots inside the rear panel and using Item **G** with Item **J** loosely bolt into position.
3. Using Item **F** with Item **H** loosely bolt Item **A** to Item **B**.
4. Locate Item **C** into the existing holes in each chassis member and using Item **E** with Item **H** and Item **K** bolt Item **A** into place.
5. Using Item **D** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
6. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

