



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 3

TR826 Renault Laguna II Hatch 2001>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Side Arms	E	2	M10 x 90 Bolts, Nuts & S/P Washers
C	2	17mm x 63mm Spacer Tubes	F	4	M12 x 35 Bolts, 2 Nuts & 4 S/P Washers
			G	4	M8 x 30 Bolts & S/P Washers
			H	2	10 x 50 Flat Washers
			J	4	12 x 25 Flat Washers
			K	4	8 x 25 Flat Washers
			L	4	M8 Metal Caged Nuts
			M	2	10 x 25 Flat Washers

1. Locate the existing holes in the rear panel and insert item L.
2. Using item G with item K loosely bolt item A to the rear panel.
3. Locate and remove the plastic bungs in the side of each chassis member.
4. Using item F with item J loosely bolt item B to item A.
5. Using item E with item H, item M and item C located into the chassis from the outer face bolt item B into place.
6. Using item D bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

