



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 3

## TR849 RENAULT MASTER CHASSIS CAB (RWD) INGIMEX DROPSIDE 2005> RENAULT MASCOTT

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	F	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	L/H Side Plate	G	8	M12 x 45 Bolts & 8 Nyloc Nuts
C	1	R/H Side Plate	H	16	12 x 25 Flat Washers
D	2	Clamp Plates	J	6	M14 x 45 Bolts, 6 Nyloc Nuts & 2 S/P Washers
E	1	Spacer Plate			

1. Remove the four fixings securing the light board to the chassis brackets.
2. Remove the four fixings securing the chassis brackets to the chassis. (Retain chassis brackets in case Towbar is removed.)
3. Open the four existing holes in each end of the chassis to 13mm.
4. Using Item G with Item H loosely bolt Item B and Item C to the outer face of each chassis with Item D placed on the inner face.
5. Using Item J bolt Item A to Item B and Item C.
6. Using the original bolts refit the lighting board to the new mounting points on the Towbar.
7. Using Item F with Item E bolt the ball bracket (not supplied in this kit) to the mounting plate. (Item E can be used as a coupling spacer or behind the face plate as a strengthening plate.)
8. Fully tighten all nuts and bolts and ensure the Towbar is rigid and secure.

**Note:**

Nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

