



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 4

TS 1102 SAAB SPORTS SAL/SPORTS HATCH/SPORTSWAGON (ESTATE)/CONVERTIBLE 2002> CADILLAC BLS 2006>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	F	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	Angle Bracket	G	1	M16 x 65 Sets, Nut & S/P Washer
C	4	Clamp Plates	H	2	M12 x 75 Grade 10.9 Bolts & Nyloc Nuts
D	1	Spacer	J	4	M10 x 50 Bolts, Nuts & S/P Washers
E	1	Extension Bar	K	2	M10 x 30 Bolts & S/P Washers
			L	4	12 x 25 Flat Washers
			M	4	10 x 25 Flat Washers
			P	1	Socket Plate

1. Remove the rear bumper. Two fixings around each wheel arch, two fixings along bottom edge either side by wheel arch, two fixings along the lower bumper near to spare wheel well some models have two fixings under each light cluster. If fitted remove the reversing sensors. Ensure bumper is unclipped at each end and pull bumper rearwards.
2. Cut a section from the lower edge of the bumper 65mm wide x 124mm deep. (If required trim to suit.)
3. Using Item J with Item M and Item C loosely bolt Item A to the bumper beam through the existing holes provided.
4. Using Item K loosely bolt Item B to the existing threaded mounting points in the spare wheel well.
5. **Sportswagon Models Only:** Using Item G with Item D bolt Item A to Item B. All other models Item D is not required.
6. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
7. Refit the bumper.
8. Using Item H with Item L bolt Item E and Item P to Item A.
9. Using Item F bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.

Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

