



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

Type TS850 Suzuki Vitara swb 89> lwb 91> & V6 diesel

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	C	2	M16 x 50 Bolts Nuts & Washers
B	2	Handed Side Arms	D	4	M12 x 30 Bolts Nuts & Washers
			E	4	M12 x 30 1.25 Bolts & Washers
			F	4	12 x 25 Flat Washers

1. Remove the towing eyes from each chassis member (if fitted).
2. Using item E with item F loosely bolt item B to the underside of each chassis member (see sketch).
3. Using item D bolt item A to item B. (If clearance is restricted on the left side gently bend the fuel tank protection plate to allow easier access).
4. Using item C bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
5. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

