



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 3

TS855 Subaru Forester 97>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	H	2	M16 x 50 Bolts Nuts & Washers
B	1	6 Hole L/H side angle	J	6	M12 x 35 Bolts 5Nuts 6 Washers
C	1	5 Hole R/H side angle	K	2	M12 x 120 Bolts Nuts & Washers
D	1	4 Hole R/H side angle	L	2	M12 x 40 x 1.25 Bolts & Washers
E	1	R/H2 Hole angle extension arm	M	1	M10 Nuts & Washers only
F	1	L/H2 Hole shorter extension angle	N	4	12 x 25 Flat Washers
G	2	19 x 82 Spacer Tubes	P	2	12 x 40 Flat Washers

1. Remove the rear exhaust hanger. Remove towing eye on right hand side (if fitted).
2. Remove the small bracket securing the centre of the bumper. (This is no longer required), but keep the fastener.
3. Using the existing bolts, loosely attach item **B** and item **C** to the underside of the chassis.
4. Using item **J** bolt item **D** to item **C**.
5. Using item **J** loosely bolt item **A** to item **B** and item **D**.
6. Locate item **G** into each chassis member and using item **K** with item **P** loosely bolt item **E** and item **F** into place.
7. Using item **L** with item **N** bolt item **E** and item **F** to each side arm and into each chassis.
8. Using the existing fastener attach the bumper to the centre of the Towbar.
9. Using item **H** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
10. Using item **M** (nut and washer) bolt the exhaust hanger to the left hand side arm.
11. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

