



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TT 6 TOYOTA VIGO 2009> WITH PAINTED BUMPER STEP

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	E	2	M16 x 75 Bolts, Nuts & S/P Washers
B	2	Side Arms	F	6	M14 x 40 Bolts & Nyloc Nuts
C	1	Coupling Spacer	G	2	M12 x 90 Bolts & Nyloc Nuts
D	2	19 x 58 Spacer Bushes	H	4	M12 x 40 x 1.25 Bolts Grade 10.9 & S/P Washers
			J	2	12 x 40 Flat Washers
			K	4	12 x 25 Flat Washers
			L	1	25mm Ally spacer

1. Remove the rear bumper from the chassis members.
2. Remove the bumper arms from the bumper and retain fixings (X).
3. Using Item **G** with Item **D** and Item **J** loosely bolt Item **B** to the existing forward hole in each chassis member.
4. Using Item **H** with Item **K** loosely bolt side arms Item **B** to the chassis members.
5. Using Item **F** bolt Item **A** to Item **B**.
6. Using Item **E** and Item **C** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
7. Using original bumper fixings (X) refit the bumper to item **A**.
8. Fully tighten all nuts and bolts and ensure the towbar and bumper step are rigid and secure.

Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

