



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 3

TT885 Toyota Picnic '96>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	E	2	M16 x 50 Bolts Nuts & Washers
B	1	L/H Side Arm	F	2	M12 x 35 Bolts x 1.25, 2 S/P Washers
C	1	R/H Side Arm	G	4	12 x 25 Flat Washers
D	1	Angle Bracket	H	2	M12 x 35 Bolts, 2 S/P Washers

1. Lower the spare wheel.
2. Remove the towing eyes from each chassis member.
3. Cut a slot in the lower edge of the bumper (see sketch).
4. Using the original bolts loosely bolt item **B** to the existing threaded holes in the side of the chassis.
5. Using the original bolts loosely bolt item **C** and item **D** to the existing threaded holes in the chassis.
6. Using item **F** with item **G** and item **H** with item **G** bolt item **A** to item **B**, item **C** and item **D**.
7. Using item **E** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
8. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
9. Replace the spare wheel.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

