



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TA1 TATA Loadbeta Pickup 1994>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	B	2	M16 x 50 Bolts, Nuts & S/P Washers
			C	4	M12 x 140 Bolts, Nuts & S/P Washers
			D	4	12 x 40 Flat Washers
			E	4	12 x 25 Flat Washers

1. Remove the towing eye from the left hand chassis (this is no longer required).
2. Using Item C with Item D and Item E bolt Item A to the existing holes in each chassis member.
3. Using Item B bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
4. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

