



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

## Type TV340 Vauxhall Combo Van 1993>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	C	4	19 x 59 Spacer Tubes
B	2	Clamp Plates	D	2	M16 x 50 Bolts, Nuts & S/P Washers
			E	4	M12 x 90 Bolts, Nuts & S/P Washers
			F	4	12 x 25 Flat Washers

1. Remove the spare wheel, to make access easier remove the exhaust off the rear hanger.
2. Locate the three dimples each side above each chassis member, drill the **outer holes only** 13mm down through the chassis, **open the top holes** only to 20mm.
3. Place item C down into each hole, place item B over the holes and pass item E down through the tubes, bolt item A to the underside of the chassis.
4. Using item D bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
5. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
6. Replace the exhaust and spare wheel.

**Note:** nose load limits and vehicle manufactures trailer / caravan weight limits must be observed.

