



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

## Type TV 346 Vauxhall Frontera SWB / LWB October 98 >

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	Angle bracket	E	7	M12 x 40 x 1.25 Bolts, 4 Nuts 7 S/P Washers
C	1	Extension bar	F	2	M12 x 100 Grade 10.9 bolts Nyloc Nuts & Special Disc Washers
			G	2	12 x 40 Flat Washers
			H	7	12 x 25 Flat Washers

- Using item E with item H loosely bolt item A to the right hand chassis member
- Using item E with item G loosely bolt item A to the existing holes in the left hand towing eye
- Using item E with item H loosely bolt item B to item A and to the left chassis member
- Using item F with item H bolt item C to item A (extended if spare wheel is fitted or retracted if no spare wheel is fitted)
- Using item D bolt the ball bracket (not supplied in this kit) to the mounting plate
- Fully tighten all nuts and bolts and ensure the towbar is rigid and secure

**Note:** Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed

