



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TV 3 VK VAUXHALL ASTRA HATCH 2009>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	1	Flip Up Socket Plate
B	1	Handed Side Arms	E	2	M12 x 22 Bolts & S/P Washers
C	1	Detachable Housing	F	6	M12 x 40 Bolts, 4 Nuts & 6 S/P Washers
			G	4	M10 x 35 Bolts & S/P Washers
			H	4	12 x 25 Flat Washers
			J	4	10 x 30 Flat Washers
			K	2	M12 x 25 Bolts & S/P Washers
			X	4	Original Nuts

1. Remove the rear bumper, two fixings along the lower edge and four fixings around wheel arches pull bumper tips outwards then rewards to release.
2. Remove bumper beam (this is not refitted with Towbar assembly).
3. Insert items **B** into each correct chassis and loosely fix in place with items **G** and items **J** through the vertical mounting points on the lower face of each chassis.
4. Using original Nuts fix items **B** to the lower studs on rear panel.
5. Using items **F** bolt item **A** between items **B**.
6. Using items **E** with item **H** and item **K** with item **H** bolt item **C** and item **D** to item **A**.
7. Fully tighten all nuts and bolts ensuring Towbar is rigid and secure.
8. Cut bumper as shown refit the rear bumper.

Note: nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

