



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 3

Type TVW615 Volkswagon Passat 97>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	E	4	M12 x 35 Bolts, Nuts & S/P Washers
B	2	L/H & R/H Side Arms	F	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts
C	1	Extension Bar	G	4	M10 x 100 Bolts, 2 Nuts, 4 S/P Washers
D	2	M16 x 50 Bolts, Nuts Washers	H	8	12 x 25 Flat Washers
			J	6	10 x 30 Flat Washers
			K	1	Socket Plate

- 1.** Remove the rear bumper (2 screws on the top edge, six screws along the bottom edge, three screws and a steel clip around each wheel arch). Facelift models from 2001 remove rear light clusters from Saloon only.
- 2.** Remove the aluminium beam and mounting brackets (these are no longer required).
- 3.** Locate item B into ends of each chassis member and using item G with item J loosely bolt into position (these holes are underneath tape and mastic).
- 4.** Using item E with item H bolt item A to item B.
- 5.** Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
- 6.** Re-fit the bumper.
- 7.** Using item F and item H bolt item C to item A.
- 8.** Using item D bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.

Note: nose load limits and vehicle manufacturers' trailer/caravan weight limits must be observed.

