



Tow-Trust Towbars

Important:

Please Read General Notes (overleaf) Before Fitting:

Issue 1

TVW 622 Volkswagon Touareg 2003>

Item	Qty	Description
A	1	Towbar
B	2	M16 x 50 Bolts, Nuts & S/P Washers

1. Remove rear bumper. Four fixings along the lower edge, four fixings in each wheel arch and two fixings under each light cluster. NOTE: Light clusters are not easily removed, to release, carefully pull light cluster rearwards. It is not recommended to use any form of tools to lever the light clusters out as they crack very easily.
2. Remove the four original fixings securing the crash beam. Retain these fixings.
3. Using original fixings bolt Item **A** to rear panel.
4. Fully tighten all bolts and ensure the towbar is rigid and secure.
5. Cut a section from the lower edge of the bumper 65mm wide x 125mm deep. If required trim to suit.
6. Refit bumper.
7. Using Item **B** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.

Note:

1. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

