



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 4

**TVW622 VK VOLKSWAGON TOUAREG 2003>
AUDI Q7 2006>
PORSCHE CAYENNE 2006>**

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	C	3	M12 x 25 Bolts Grade 12.9 & S/P Washers
B	1	Detachable housing	D	1	M12 x 25 Bolt Grade 12.9 & S/P Washer
			F	1	Socket Plate
			G	2	ACS Lock Washers
			H	3	12 x 25 Flat Washers

1. Remove rear bumper. Four fixings along the lower edge, four fixings in each wheel arch and two fixings under each light cluster. NOTE: Light clusters are not easily removed, to release, carefully pull light cluster rearwards. It is not recommended to use any form of tools to lever the light clusters out as they crack very easily.
2. Remove the four original fixings securing the crash beam. Retain these fixings.
3. Using original fixings bolt Item **A** to rear panel.
4. Using Items **C** with Items **G** and Item **D** with Item **G** bolt Item **F** and Item **B** to Item **A**.
5. Fully tighten all bolts and ensure the Towbar is rigid and secure.
6. Cut a section from the lower edge of the bumper 85mm wide x 125mm deep. If required trim to suit.
7. Refit bumper.

Note:

1. Nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.
2. Grade 12.9 Bolts 145Nm

