



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 6

TVW 623 Volkswagen Golf 2004>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Side Arms	E	6	M12 x 50 Bolts & S/P Washers
C	1	Extension	F	2	M12 x 85 Bolts Grade 10.9 & Nyloc Nuts
			G	10	12 x 25 Flat Washers
			H	2	5mm End Plate Lasers

1. Remove the rear light clusters.
2. Remove rear bumper. Fixings along the lower edge, under each light cluster and around each wheel arch.
3. Remove the bumper crossbeam (this is not refitted). Replace existing bolts.
4. Locate Item B inside each chassis and using Item E with Item G loosely bolt to forward existing holes (these are covered with tape).
5. Using Item E with Item G loosely bolt Item A to Item B and through existing rearmost holes. Fully tighten all bolts.
6. **Golf 5:** Cut out a section 65mm x 125mm centrally from the lower edge of the bumper.
7. **Golf 6:** Cut out a section 65mm x 80mm centrally from the lower edge of the bumper.
8. Refit bumper and light clusters.
9. Using Item F with Item G bolt Item C to Item A.
10. Using Item D bolt the ball bracket (not supplied in this kit) to the mounting plate.

Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

