



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 4

TVW 623VK Volkswagen Golf 2004>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	1	M12 x 25 Bolts & S/P Washers
B	2	Side Arms	E	6	M12 x 50 Bolts & S/P Washers
C	1	Detachable Housing	F	3	M12 x 22 Bolts & S/P Washers
			G	10	12 x 25 Flat Washers
			H	1	Small Angle Socket Plate
			K	2	5mm End Plate Lasers

1. Remove the rear light clusters.
2. Remove rear bumper. Fixings along the lower edge, under each light cluster and around each wheel arch.
3. Remove the bumper crossbeam (this is not refitted). Replace existing bolts.
4. Locate Item B inside each chassis and using Item E with Item G loosely bolt to forward existing holes (these are covered with tape).
5. Using Item E with Item G loosely bolt Item A to Item B and through existing rearmost holes. Fully tighten all bolts.
6. Using Item F with Item G and Item D with Item G bolt Item C and Item H to Item A and fully tighten.
7. Remove the lower BLACK diffuser from rear bumper and replace with new original equipment Diffuser and Tow-Flap (ordered separately from Volkswagen Dealer).
8. Refit bumper and light clusters.

Important Information: This towbar is for use with Volkswagen original equipment bumper diffuser with cut out and tow-flap panel.

Please contact Volkswagen dealer with vehicle description and vehicle identification number (VIN) to source the correct parts

Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

