



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 7

Type TL259 Land Rover Freelander 2 2006>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	E	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	L/H Side Bracket	F	3	M10 x 40 Grade 10.9 Bolts, Nuts & S/P Washers
C	1	L/H Chassis Bracket	G	2	M14 x 90 x Bolts & Nyloc Nuts
D	1	Extension Bar	H	2	M14 x 100 Bolts & S/P Washers
			J	2	M12 x 35 Grade 10.9 Bolts, Nuts & S/P Washers
			K	6	14 x 27 Flat Washers
			M	3	10 x 25 Flat Washers

1. Remove the five fasteners from the lower edge of the bumper, and the left hand bumper reflector.
2. Drill two 20mm holes **SEE SKETCH** in the reflector recess..
3. Using Item H with Item K loosely bolt Item B to the forward existing threaded hole in the left hand chassis member.
4. Remove the two M8 nuts from the existing studs on the left hand side of the rear panel.
5. Locate Item C over the studs and loosely secure using the existing nuts.
6. Using Item H with Item K loosely bolt Item C and Item B to the existing rearmost threaded hole in the left hand chassis member.
7. At this point fully tighten the two M8 nuts securing Item C.
8. Using Item J loosely bolt Item A to Item B.
9. Using Item F with Item M bolt Item A to the existing holes in the right hand towing eye.
10. Using Item G and Item K bolt Item D to Item A.
11. Using Item E bolt the ball bracket (not supplied in this kit) to the mounting plate.
12. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
13. Replace existing fasteners in the lower edge of the bumper.

Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

